

<b>LIVE&amp;BAR Room61</b>		EVENT TITLE :
		F.O.H
		MONITER
日時 :	STAGE LIGHTNING	
INPUT&PLOT1	ASSISTANT :	

WING INPUT								
CH	BOX	INST	MIC/DI	INSERT	STAND	48V	DCA	MUTE
1	17/18	OH	C451B		MS205BK	●	DRUM	1,4
2	19	KICK IN	BETA91A			●	DRUM	1,4
3	20	KICK OUT	BETA52A		MS205STBK		DRUM	1,4
4	21	KICK TRIGGER	TM-2			●	DRUM	1,4
5	22	SNARE TOP	SM57		MS436LBK		DRUM	1,4
6	23	SNARE BOT	SM57		MS436LBK		DRUM	1,4
7	24	HH	C451B		MS436LBK	●	DRUM	1,4
8	25	HT	E904				DRUM	1,4
9	26	LT	E904				DRUM	1,4
10	27	FT	ATM25		MS205STBK		DRUM	1,4
11								
12								
13	1	VOX1	SM58/MTP550DM		MS205BK		VOX	2,4
14	2	VOX2	SM58/MTP550DM		MS205BK		VOX	2,4
15	3	VOX3	SM58/MTP550DM		MS205BK		VOX	2,4
16	4	VOX4	SM58/MTP550DM		MS205BK		VOX	2,4
17	28	DRUMVOX	BETA56A		MS205BK		VOX	2,4
18	29	SL.GU	SM57		MS205STBK		INST	3,4
19	9	SR.GU	SM57		MS205STBK		INST	3,4
20	31	BASS LINE	DI			●	INST	3,4
21	32	BASS MIC	SM57		MS205STBK		INST	3,4
22	13	DI	DI			●		4
23	14	DI	DI			●		4
24	15	DI	DI			●		4
25	16	DI	DI			●		4
26								
27								
28								
29								
30								
31								
32								
33								
34								
35								
36								
37								
38								
39								
40								

OTHER CH			
	DCA	BUS	EFE
1	VOX	SL	HALL REV
2	DRUM	CENTER	ROOM REV
3	INST	SR	ST DEL
4	BGM	DRUM	ROOM REV
5		IEM1	
6		IEM2	
7			EXTERNAL
8			EXTERNAL
9		VOX REV	GEQ
10		VOX DEL	GEQ
11		DRUM REV	GEQ
12		INST REV	GEQ
13		VOX MASTER	GEQ
14		DRUM MASTER	
15		INST MASTER	
16			

AUX IN		
1	CD/L	A1
2	CD/R	A1
3	CD/L	A2
4	CD/R	A2
5	PC/L	A3
6	PC/R	A3
7		
8		

S16 OUT PATCH			
1	SL	9	
2	CENTER	10	
3	SR	11	
4	DRUM	12	
5	IEM1	13	
6	IEM2	14	
7		15	
8		16	