

# LIVE&BAR Room61

DAY:

EVENT TITLE:

F.O.H:

MONITOR:

## BEHRINGER WING CH-IN OUT LIST

### WING INPUTS CH

CH	BOX	INST	MIC/DI	INSERT	STAND	48V	MUTE*
1	17/18	OH (stereo)	C451B *2		MS205BK	•	1,4
2	19	KICK IN	BETA91A			•	1,4
3	20	KICK OUT	BETA52A		MS205STBK		1,4
4	21	KICK TRIGGER	TM-2			•	1,4
5	LCL4	SNARE TOP	SM57 Unidyne III	HA-73X2	MS436LBK		1,4
6	23	SNARE BOT	SM57		MS436LBK		1,4
7	24	HIHAT	C451B		MS436LBK	•	1,4
8	25	10" TT	E904		CLIP		1,4
9	26	12" TT	E904		CLIP		1,4
10	27	16" FT	ATM25		MS205STBK		1,4
11							
12	AUX1/2	CD-500	CD				4
13	1	VOX1	MTP550DM		MS205BK		2,4
14	1	VOX1 FB					2,4
15	2	VOX2	MTP550DM		MS205BK		2,4
16	2	VOX2 FB					2,4
17	3	VOX3	MTP550DM		MS205BK		2,4
18	3	VOX3 FB					2,4
19	4	VOX4	MTP550DM		MS205BK		2,4
20	4	VOX4 FB					2,4
21	28	DRUM VOX	BETA56A		MS205BK		2,4
22	28	DRUM VOX FB					2,4
23							
24							
25	29	SR GU	SM57		MS205STBK		3,4
26	9	SL GU	SM57		MS205STBK		3,4
27	LCL3	BASS DI	TYPE85	HA73-X2		•	3,4
28	32	BASS MIC	SM58 USA		MS205STBK		3,4
29	13	DI	TYPE85			•	3,4
30	14	DI	TYPE85			•	3,4
31	15	DI	TYPE85			•	3,4
32							
33							
34							
35							
36							
37							
38							
39							
40	LCL1	PA MIC	SM58				

### AUX CH

CH	INPUT	INST
1	AUX3/4	CD-200
2	AUX5/8	PC-SE
3	AUX7/8	MINI PIN
4		
5		
6		
7		
8	LCL1	TALK BACK

### BUS CH

CH	NAME	CH	NAME
1	SR MONI	9	VOX ROOM REV
2	CENTER MONI	10	VOX HALL REV
3	SL MONI	11	VOX DELAY
4	DRUM MONI	12	DRUM REV
5	IEM1	13	INST REV
6	IEM2	14	VOX BUS
7	IEM3	15	DRUM BUS
8	IEM4	16	INST BUS

### MAIN MATRIX CH

CH	NAME	CH	NAME
MAIN1	LR	MATRIX1	F.O.H (LR + M/C)
MAIN2	M/C	MATRIX2	
MAIN3	STREAMING OUT	MATRIX3	
MAIN4		MATRIX4	
		MATRIX5	
		MATRIX6	
		MATRIX7	
		MATRIX8	

### S16 OUTPUT PATCH

1	SR MONI	9	
2	CENTER MONI	10	
3	SL MONI	11	
4	DRUM MONI	12	
5	IEM1	13	
6	IEM2	14	
7	IEM3	15	
8	IEM4	16	

(\*MUTE GROUP 1:DRUM , 2:VOX , 3:INST , 4:ALL)